

Fishman F1 Aura® Quick Start

Plug In



Tune Up

Press and hold the volume knob for 2 seconds until "1" is displayed. Release the volume knob. Tune up. Press and release the volume knob to turn the tuner off.

Turn Up

Raise the volume to a desirable level.



Changing the Blend (Optional)

Turn the edit knob to adjust the blend between the under-saddle pickup and the microphone image outputs.



Selecting an Image (Optional)

Press and release the edit knob once and the letter "I" will be displayed. Turn the edit knob to select one of nine different microphone images.

Play the guitar and have fun!

Advanced Features

- Phase Control
- Pickup EQ
- Blend (Pickup and Microphone Image Outputs)
- Compressor
- Anti-Feedback
- Image Sound EQ

